
Deck Joints and Bearings


Deck Joints and
Bearings


Technical Standards Branch
Class A Bridge Inspection Course


BIM







































































Deck Joints and Bearings

# **Problems and Inspection Considerations**


- Observe traffic passing over joints
  - listen for unusual noises and watch for movement of the joint
- · Check drainage system
  - plugging of joint opening, troughs and downpipes with debris


  - cracks, breaks or tears in any component
  - integrity of attachments and connections
    - · loose or missing bolts
    - · cracked or broken welds
    - · loose or open connections
  - Check for:
    - signs of ponding on the deck
    - staining or deterioration on the deck, curbs, girders and substructure
    - erosion below downpipe





Technical Standards Branch
Class A Bridge Inspection Course











Deck Joints and Bearings

# **Deck Joint Inspection and Rating**

- · Rate according to existing condition and functionality
- · Includes condition and functionality of drainage system
- Leakage of sealed joints is reflected in both the deck joint rating and the deck drainage rating
- Defects in open joints with plumbing features are also reflected in both the deck joint rating and the deck drainage rating
- Leakage problems with open joints without plumbing are rated under deck drainage only
- Curb cover plates are rated with the deck joint and not the curb rating



Technical Standards Branch
Class A Bridge Inspection Course 32

BIM

Deck Joints and Bearings

# **Deck Joint Inspection and** Rating

- Joints that are not fully free to move
  - rate 4 or less
- Watertight joints which allow leakage of water onto girders, bearings or substructure
  - rate 4 or less
- Open (non-watertight) joints should not be down rated because of leakage
- Joint defects causing problems with structure rate 3 or less
- Joints which are a hazard to traffic
  - rate 2



Technical Standards Branch
Class A Bridge Inspection Course 33



Deck Joints and Bearings

Deck Joints and Bearings

### **Bearings**

- · Bearings must transfer loads from the superstructure to substructure.
- The bearings accommodate movement caused by temperature changes, deflection, earth pressures, etc.
- Bridge bearings are generally classified as fixed or expansion type.
- · Fixed bearings allow rotation but no vertical or horizontal movement.
- Expansion bearings allow both rotation and longitudinal movement of the superstructure. Expansion bearings sometimes also permit transverse movement.



Technical Standards Branch
Class A Bridge Inspection Course




**Bearings** 


- There are usually three distinct components in a bearing:
  - Sole plate
    - steel plate welded, bolted, riveted or cast to bottom of girders
  - Masonry plate
    - similar to sole plate except located on top of substructure element and usually anchored by bolts into concrete
  - Bearing
    - assembly between sole plate and masonry plate that permits movement of the bridge





Technical Standards Branch
Class A Bridge Inspection Course









































Deck Joints and Bearings

## **Bearings**

### **Problems and Inspection Considerations**

- Dirt or debris
  - may inhibit movement
  - promotes corrosion
- Corrosion
  - "frozen" bearing (2016 bulletin regarding "Type O" bearings)
  - deterioration of bearing
  - especially under leaking joints
- Loose or missing connections, cracked or broken welds
- Loss of bearing contact or uneven contact
  - rollers moved off masonry or sole plates
  - neoprene pads creeping out of position
  - can overstress steel or concrete members



Technical Standards Branch
Class A Bridge Inspection Course



Deck Joints and Bearings

### **Bearings**

### **Problems and Inspection Considerations**

- Wear
- Rocker alignment
  - overextension
  - should be approximately vertical at 0º Celsius
- Failure of elastomer
  - splitting, cracks, squeezing out, bulging
  - separation of the elastomer at reinforcing plates



Technical Standards Branch
Class A Bridge Inspection Course



# Bearings Problems and Inspection Considerations Anchor bolts corrosion (strike with hammer) bent surrounding concrete cracked nuts not properly secured (jam nut), nuts missing binding on shoe plate or bearing device Indications of a non-functioning bearing cracks in the bearing area of the substructure or superstructure uneven gaps at expansion joints

**Bearings** Inspection Form and Rating · Record temperature · Record or verify bearing types and locations: expansion fixed · Record or verify if coating is intact and functioning to protect the bearing from corrosion • Record or verify whether the bearing is functioning as designed - proper bearing - proper movement Technical Standards Branch
Class A Bridge Inspection Course BIM 53

Deck Joints and Bearings



· bump at joint

• jammed joint

• joint gap too wide

• variable gap in same joint

- misalignment of superstructure at joint

